TISPLUS

TISPLUS SCAN HANDLE FOR ZEBRA TC75

1. INSERTION

1.   Take the TC75 and put it into the left holder of the handle.

2.   Align the lower left side of the handle holder to the edge of the black TC75 rubber.

3.   Now push the right side of the TC75 down and

4.   move the handle a little bit forward until the lock catches snap into the holes at the TC75 battery release buttons.

5.   Then push the right holder of the handle until it snaps over the right side of the TC75.

**Now press down the left and right hand side of the retaining clip until it snaps.
Ready!**

Lock latches

2. Align	4. Move till "snap"	5. Push	"click"

Note:
The TISPLUS Scan Handle is desined to carry the TC75 with mounted hand strap. For easy insertion please put the hand strap in a flat position.

For charging with mounted handle please push the hand strap in the upper position.

TIS

TISPLUS

TISPLUS SCAN HANDLE FOR ZEBRA TC75

2. REMOVAL

Push the right holder of the handle until it moves above the right side of the TC75. Turn the TC75 out of the handle.

Push

3. PTT-BUTTON REMAPPING

The TIS Scan Handle uses the PTT-Button to trigger the scanner. Please remap the PTT-Button with the following instructions:

1. Start Settings->Key Programmer
2. Click on "BUTTON_PTT"
3. Scroll up click on "Scan Button"
4. Ready, screenshot on the right shows the remapped PTT-Button for TIS Scan Handle usage

4. STYLUS MOUNTING

For easy access to the TC75 stylus the TIS Scan Handle provides a holder for the stylus and a hole to mount the stylus cord. The picture shows the TIS Scan Handle with mounted stylus.

5. CARE

Do not use oil to lubricate the mechanism. Oil detracts plasticizers from the material, the plastic parts become brittle.
Do not use harsh chemicals, cleaning solvents or strong detergents to clean the TISPLUS Scan Handle. Clean the TISPLUS Scan Handle with a damp cloth.

File: USER GUIDE TIS PLUS SCAN HANDLE FOR ZEBRA TC75 Stand: 5.7.2016