

TISPLUS SCAN HANDLE FOR DOLPHIN EDA50

QUICK INSTALLATION GUIDE

1. Remove sticker

Remove the sticker from the back of your EDA50 handheld as shown..



2. Mounting of snap-on pole

Use a screwdriver of size PH1 (not included in delivery) to mount the snap-on pole in the exposed tapped hole.



3. Mounting of Scan Handle

Slide the scan handle onto the device as shown

... until it snaps onto the snap-on pod.



REMOVAL OF HANDLE

Hold the handle firmly with one hand and press the thumb against the bottom edge of the EDA50 until the handle snaps out of the snap-on pod.

Then remove the device.

